

Series 3 Technician's Installation and Service Training Manual

Marantec External Receiver Installation and Wiring Instruction



Warning Electrical Shock Hazard

To prevent serious injury or death always ensure power is disconnected when wiring anything into the ZAP Controller.

Materials required

Marantec receiver (Figure A), appropriate Marantec transmitter, 16-20 awg 2 conductor cable.

Tools required

Small technicians slotted screwdriver

Isolate the power supply before wiring any device into a ZAP Controller.

All wiring for the radio receiver onto the ZAP control board is connected to the radio wiring connections as indicated in (Figure A) and highlighted in red.

Terminal 1 (Right) on the Marantec receiver (Figure C) is wired and terminated into the 0V connection on TB9. (Figure D)

If cyclic operation by radio control is desired, The relay terminal (Left) on the Marantec receiver (Figure E) is wired and terminated into the Radio connection on TB9. (Figure F)

If only an open function is required (If use of the auto-close timer is employed, it is recommended that only the open be used), wire the relay terminal (Left) on the Marantec receiver (Figure E) to the open connection on TB3. (Figure G)

Plug the receiver into the 115V power supply. (Figure H)

Restore the power supply and program your receiver per the radio control manufacturer's instructions. (Figure I)



Figure A




Figure B



Figure C




Figure D



Figure E




Figure F




Figure G



Figure H



Figure I

ZAP Series 3 Simply Logical

ZAP Controls
100 Waterloo Blvd. Anglesey Business Park, Littleworth Road, Cannock, Staffordshire, England
UK Contact 011-44-154-387-9444 sales@zap-uk.com
USA Contact 931-510-4432 sales@zap-america.com
USA Tech Support 931-510-4432 via telephone or text
Online www.zap-uk.com