## Series 3 Technician's Installation and Service Training Manual

## 82DTLM to Control Accessory ON/OFF Wiring Instruction



## **Warning Electrical Shock Hazard**

To prevent serious injury or death always ensure power is disconnected when wiring anything into the ZAP Controller.

Isolate the power supply before wiring any device into a ZAP Controller.

The 82-DTLM provides a series of relays that will close a contact to send a signal to cause an accessory to turn on in the following scenarios:

Upon the door entering it's open cycle- Relay Close (Red) When fully closed the relay is open,

Upon fully opening - Relay Close (I-lock) When not fully open the relay is open

Upon fully closing- Relay Close (Green) When not fully closed the relay is open

Relays are rated for voltages up to 250V and 6 amps.



## **ZAP Series 3 Simply Logical**

**UK Contact** USA Tech Support Online

**ZAP Controls** 

011-44-154-387-9444 931-510-4432 931-510-4432 www.zap-uk.com

100 Waterloo Blvd. Anglesey Business Park, Littleworth Road, Cannock, Staffordshire, England sales@zap-uk.com sales@zap-america.com via telephone or text