

ZAP Series 3 Technical Manual

Auto-Close Timer Programming



Warning Electrical Shock Hazard

To prevent serious injury or death always ensure power is disconnected when wiring anything into the ZAP Controller.

Start with the door in the fully closed position.

Enable the Auto-Close timer by setting DIP switch No. 4 to ON. (Figure A)

Press and hold the program button. (Figure B)

Release the button after the 2nd flash of the ACK LED or beep if the 850 beeper module is installed. (Figure C)

Next press the OPEN push button.

After the door has fully opened and the operator open LED has turned off. Begin timing on your watch the desired close delay. Maximum is 4 Minutes.

When the desired time delay is reached, press the CLOSE push button twice. The desired delay is now stored into the memory and will be retained during any power interruptions.

The programming process pressing the button twice will ensure the door closes regardless of obstruction for security reasons.

If you prefer that the door should reopen and stay open following an obstruction strike, then only press the close button once, instead of twice, as described above.

If you wish to change programmed delay, simply repeat the programming function.




Figure A



Figure B



Figure C

ZAP Series 3 Simply Logical

ZAP Controls
100 Waterloo Blvd. Anglesey Business Park, Littleworth Road, Cannock, Staffordshire, England
UK Contact 011-44-154-387-9444 sales@zap-uk.com
USA Contact 931-510-4432 sales@zap-america.com
USA Tech Support 931-510-4432 via telephone or text
Online www.zap-uk.com